



17 Wheeler Gate, Westport, CT 06880 Tel: (203)227-1917 Fax: (203)227-0437

September 2014

Sungal Rolling Product Shelf (RPS) Cleaning Instructions (Intertek Sanitation Listed, Conforms to NSF Standard 2)

Option 1: Light Stains.

Use a damp cloth or paper towel to gently wipe leakage from soft drinks, soaps, detergents, etc. A combination of horizontal/vertical/circular motions while cleaning is best. Use a dry cloth or paper towel to dry surfaces.

Option 2: Sticky/Greasy Stains.

If shelf is cleaned in place, cover the shelf immediately below. Apply window cleaner without bleach or water-based “Goo Gone” to problem area (follow manufacturer’s directions). Scrub gently as above to work cleanser into affected area. Spray light amounts of water and wipe with dry towels to rinse through completely.

Option 3: Extremely Difficult Spills.

Shelf may need to be removed as power washing may be necessary. If debris/goos impedes rolling pins, carefully remove pins and clean as necessary, and apply power wash to rolling pin tracks. Wipe off excess moisture and allow to dry naturally. Carefully re-insert rolling pins into the tracks. Be sure pins roll freely before re-installing shelf.